

UTC

1548 24/5/17 Start logging
1730 water on

File 0002: thought I had changed config
file but I hadn't.

File 0003: Flow wasn't plugged in
IS now. MK

2017-06 LING P

0304 5 JUNE UTC
START 0001 TSG

1438 6 JUNE UTC

NOTICED THAT GPS SIGNAL TO SERVER LOST
TSG POSITION NOT UPDATED SINCE BEFORE P

1503 6 JUNE UTC

START FILE 0002 AFTER REBOOTING SERVER.
48'40.04 126'52.64

0115 Sun 18 JUNE UTC

Realise that the flow is at 0
Water still flowing ok, but signal went to 0
At day 167.675. The flow meter seems to
have died.